INSTRUCTIONS FOR THE USE AND CARE OF YOUR METRO OMNIVAC – MODEL OV-4BCSF

1. **Start appliance by pushing the toggle switch to either "low or hi" speeds.**

2. **HOSE: When use of hose is desired, connect to suction end of the OMNIVAC for cleaning purposes, to exhaust end for blowing purposes.**

3. **EXTENSION WANDS: Reach those inaccessible spots. Eliminate bending to clean low areas and under furniture …stretching to reach high areas.**

4. **EUROSTYLE COMBO RUG/FLOOR TOOL: Depressing pedals exposes brush for bare floors or extracts brush for area rugs/carpets. Use with extension wands to clean carpeting/bare floors. Swivel action permits proper contact with all surfaces without moving low furniture.**

5. **CREVICE TOOL: Cleans those hard-to-reach tight spots such as radiators, pianos, bedsprings, baseboards, around and between the cushions of upholstered furniture, moldings, etc.. Can be used for vacuuming and blowing purposes.**

6. **DUST BRUSH: Long soft bristles gently loosen dust on furniture, lamp shades, venetian blinds, picture frames, mouldings, bookshelves, books, window sills, banisters, etc..**

7. **"PIK-ALL" NOZZLE: Cleans stairs, upholstery, furniture, draperies, mattresses, pillows, automobile interiors, mobile homes and boat interiors.**

8. **POWERIZER/AIR MAXIMIZER: This tapered accessory concentrates and maximizes air flow for both vacuuming and blowing purposes.**

IMPORTANT

TO USE AS A BLOWER, RELEASE CLAMPS AND REMOVE FRONT END CAP AND CLOTH BAG.

TO INFLATE INFLATABLES

INFLATOR ADAPTOR: When inflating air mattresses, boats, rafts with large valves, place blowing (exhaust) end into or against valve until inflatable is filled. When inflating inflatables with small valves, place tapered adaptor onto blowing (exhaust) end, snap on to "push button" locking device. When flexibility is needed, attach flexible hose to exhaust/blowing end.

TURBO DRIVEN POWER BRUSH: The powerful air flow of the 4.0 Peak HP motor spins the turbine driven power brush at rapid speed to root out deep down hidden dirt from rugs and carpeted surfaces. (OPTIONAL)

Securely attach the turbo driven power head to the hose/wand assembly. Slide adjustment for "low/hi" pile carpets.

CAUTON

IF YOUR OMIVAC HAS SUCTION BUT DOES NOT CLEAN WHEN HOSE IS ATTACHED, REMOVE HOSE FROM SUCTION END AND PLACE ONTO BLOWER END. BLOW OUT THE HOSE … SOMETIMES IT MIGHT BE CLOGGED. TRIPLE FILTRATION INCLUDES PAPER DISPOSABLE BAG, PERMANENT CLOTH BAG AND CHARCOAL FILTER. TO PROTECT YOUR MOTOR, FOR MAXIMUM EFFICIENCY AND LONG LIFE, DISPOSE OF USED PAPER BAG, FREQUENTLY CHECK THE PERMANENT CLOTH BAG FOR DUST/DIRT BUILD UP AND CAKING, SHAKE OUT PERMANENT CLOTH BAG FREQUENTLY, CHECK AND REPLACE FOAM FILTER 3 TO 4 TIMES PER YEAR.

INSOV4